


TWELVE TONE PRODUCTIONS REMOTE DROP OFF PACKAGE INSTRUCTIONS

All Equipment and Touch Points Have Been Wiped Down and Sterilized

We will talk you through all these steps by Zoom call



1. Wheel inside to preferred location and plug power cable into wall. Then turn power strip ON.



2. Use red mark on mic cable to measure to the back of chair. Adjust chair for proper framing.



3. Press RECORD button on camera. Red light stays on.
4. Remove cover from lav mic and attach to inside of clothing.
5. Connect lav mic to mic cable

THAT'S IT!!!!

